




Roland

ANNOUNCEMENT RECORDER

AR-1000

OWNER'S MANUAL



	CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN	
ATTENTION RISQUE DE CHOC ELECTRIQUE NE PAS OUVRIR		
<p>CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.</p>		



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of un-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS.

IMPORTANT SAFETY INSTRUCTIONS

WARNING — When using electric products, basic precautions should always be followed, including the following:

1. Read all the instructions before using the product.
2. Do not use this product near water — for example, near a bathtub, washbowl, kitchen sink, in a wet basement, or near a swimming pool, or the like.
3. This product should be used only with a cart or stand that is recommended by the manufacturer.
4. This product, either alone or in combination with an amplifier and headphones or speakers, may be capable of producing sound levels that could cause permanent hearing loss. Do not operate for a long period of time at a high volume level or at a level that is uncomfortable. If you experience any hearing loss or ringing in the ears, you should consult an audiologist.
5. The product should be located so that its location or position does not interfere with its proper ventilation.
6. The product should be located away from heat sources such as radiators, heat registers, or other products that produce heat.
7. Avoid using the product where it may be affected by dust.
8. The product should be connected to a power supply only of the type described in the operating instructions or as marked on the product.
9. The power-supply cord of the product should be unplugged from the outlet when left unused for a long period of time.
10. Do not tread on the power-supply cord.
11. Do not pull the cord but hold the plug when unplugging.
12. When setting up with any other instruments, the procedure should be followed in accordance with instruction manual.
13. Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.
14. The product should be serviced by qualified service personnel when:
 - A. The power-supply cord or the plug has been damaged; or
 - B. Objects have fallen, or liquid has been spilled into the product; or
 - C. The product has been exposed to rain; or
 - D. The product does not appear to operate normally or exhibits a marked change in performance; or
 - E. The product has been dropped, or the enclosure damaged.
15. Do not attempt to service the product beyond that described in the user-maintenance instructions. All other servicing should be referred to qualified service personnel.

For Canada

For Polarized Attachment Plug

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

ATTENTION: POUR ÉVITER LES CHOCS ÉLECTRIQUES, INTRODUIRE LA LAME LA PLUS LARGE DE LA FICHE DANS LA BORNE CORRESPONDANTE DE LA PRISE ET POUSSER JUSQU' AU FOND.


SAVE THESE INSTRUCTIONS

For the U.K.

WARNING: THIS APPARATUS MUST BE EARTHED

IMPORTANT: THE WIRES IN THIS MAINS LEAD ARE COLOURED IN ACCORDANCE WITH THE FOLLOWING CODE.
GREEN-AND-YELLOW: EARTH, BLUE: NEUTRAL, BROWN: LIVE

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug proceed as follows:

The wire which is coloured GREEN-AND-YELLOW must be connected to the terminal in the plug which is marked by the letter E or by the safety earth symbol  or coloured GREEN or GREEN-AND-YELLOW.

The wire which is coloured BLUE must be connected to the terminal which is marked with the letter N or coloured BLACK.

The wire which is coloured BROWN must be connected to the terminal which is marked with the letter L or coloured RED.

The product which is equipped with a THREE WIRE GROUNDING TYPE AC PLUG must be grounded.

Thank you, and congratulations on your choice of the **Roland AR-1000 Announcement Recorder**.
 In order to enjoy command over the complete range of superior features the unit offers, please take the time to read this manual in its entirety.

FEATURES

- Highly realistic recording/playback of voice (or music) is assured thanks to adoption of the ADPCM method.
- Since your voice recordings are placed directly onto IC cards (memory cards), you will not experience any deterioration in the sound quality, or have problems with the transport mechanism as you might if using conventional recording/playback devices that use tape.
- Accommodates up to 500 Phrases (or 1,960 seconds) of recorded material. (When 2 memory cards are used.)
- The LCD display provides for the efficient confirmation of the settings you make, since it can display a whole group of settings at once.
- A comprehensive selection of playback methods is available to allow you to select the one that best suits the situation you have at hand. These include: Program Playback (2 patterns), Direct Playback (3 patterns), as well as playback which is controlled by a personal computer (using RS-232-C).
- Different methods of recording can be accommodated thanks to its two sets of inputs (LINE / MIC).
- Since it is equipped with its own speaker, it allows for trouble free monitoring of what you record.
- Can be mounted on EIA-1U rack.
- The unit facilitates mixing that similar audio sources, since the line inputs are equipped with a muting feature.

Concerning Memory Cards

Note that no memory cards are included with this product; they are available for purchase separately.
 Any memory card which complies with PCMCIA R2.0/JEIDA* Ver. 4 (SRAM and FLASH cards) is permissible.

* Japan Electronics Industries Development Association

PCMCIA compatible memory card:

A memory card which complies with the R2.0 standard specified by the PC Memory Card International Association.

SRAM cards:

SRAM stands for Static Random Access Memory, and these are cards which can be written to (recorded onto) / erased at will.

FLASH cards:

These cards can be written to (recorded onto) / erased electrically.

Capacity (Bytes)	Recording Time (Sec.)		
	Sampling rate		
	8.5kHz	17kHz	22kHz
128K	29	14	11
256K	60	30	23
512K	120	60	47
1M	243	121	94
1.5M	366	183	142
2M	489	244	190
3M	735	367	285
4M	980	490	381

(Amount afforded by a single memory card)

■ CONTENTS

■ IMPORTANT NOTES	5
■ PANEL DESCRIPTIONS	6
■ CONNECTION EXAMPLE	7

GETTING STARTED

■ RECORDING	10
● Getting Ready	10
● Making a Recording	11
● Monitoring Memory Cards (Monitor Mode)	13
■ PLAYBACK (PLAY MODE)	14
● Program Play	14
● Direct Play	16
Normal Play	16
Last – In Play	17
Ordinal Play	18

ADVANCED FEATURES

■ CHANGING THE SETTINGS FOR PHRASES	20
■ DELETING PHRASES	23
■ COPYING PHRASES	25
■ DELETING SILENT PORTIONS	27
■ PATTERN PHRASES	29
■ ERASING MEMORY CARD DATA	32
■ FORMAT OF MEMORY CARDS	34
■ GIVING CARDS A NAME	36

■ MAKING COPIES OF SRAM CARDS	38
--	----

■ MAKING COPIES OF FLASH CARDS	39
---	----

■ SYSTEM SETTINGS	40
● Setting the Target for Storage of System Data	40
● Setting the Playing Order for Program Play	42
● Assigning Phrases to Control Input Channels	44
● Setting How Play Should Take Place During Direct Play	46
● Setting for the Power On Mode	48

■ CONFIGURATION (SUB-MENU)	50
● Choice for Play Monitoring	50
● Choice for Recording Monitoring	52
● Setting the Silent Portions Deletion Function	54
● Setting the Baud Rate for RS-232-C Communications	56
● Using the LINE IN MUTE Feature	58

■ ABOUT THE CONTROL IN/OUTS

● Control Input	60
● Control Output	61
Busy Output	61
Control Output	61
● RS-232-C	62

■ ERROR MESSAGES	65
------------------------	----

■ SCALE DIAGRAM OF EXTERIOR	66
-----------------------------------	----

■ SPECIFICATIONS	67
------------------------	----

Copyright © 1992 by ROLAND CORPORATION

All rights reserved. No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.

■ IMPORTANT NOTES

In addition to the items listed under Safety Precautions on page 2, please read and adhere to the following:

[Power Supply]

- When making any connections with other devices, always turn off the power to all equipment first; this will help prevent damage or malfunction.
- Do not use this unit on the same power circuit with any device that will generate line noise, such as a motor or variable lighting system.

[Placement]

- Using the unit near power amplifiers (or other equipment containing large transformers) may induce hum.
- This unit may interfere with radio and television reception. Do not use this unit in the vicinity of such receivers.

[Maintenance]


- For everyday cleaning wipe the unit with a soft, dry cloth (or one that has been slightly dampened with water). To remove stubborn dirt, use a mild neutral detergent. Afterwards, be sure to wipe the unit thoroughly with a soft, dry cloth.
- Never use benzene, thinners, alcohol or solvents of any kind, to avoid the risk of discoloration and/or deformation.

[Additional Precautions]

- Protect the unit from strong impact.
- Do not allow objects or liquids of any kind to penetrate the unit. In the event of such an occurrence, discontinue use immediately. Contact qualified service personnel as soon as possible.
- Never strike or apply strong pressure to the display.
- A small amount of heat will radiate from the unit, and thus should be considered normal.
- Before using the unit in a foreign country, consult with qualified service personnel.


● How to Insert Memory Cards

With the brand name on the card facing upwards, insert it into the slot until it is firmly gripped in place.




● Removing Memory Cards

Press the button at the slot's right, then pull out the memory card.




PANEL DESCRIPTIONS

«Front panel»




«Rear panel»



- 1** MIC Input Jack
- 2** INPUT VOLUME Knob
- 3** Display
- 4** START Button
- 5** STOP Button
- 6** Value Altering Buttons [△]/[▽]
- 7** Item Selection Buttons [◀]/[▶]
- 8** REC MODE Button / Indicator
- 9** EDIT Mode Button / Indicator
- 10** ENTER Button
- 11** EXIT Button
- 12** KEY PROTECT Switch / Indicator
- 13** MEMORY CARD Slots
- 14** OUTPUT VOLUME Knob
- 15** POWER Switch


- 16** LINE Input Jacks
- 17** BALANCED OUTPUT Jack



- 18** PROGRAM PLAY Input Jack (page 60)
- 19** CONTROL IN / OUT Terminals (page 60)
- 20** CONTROL IN / OUT Connector (page 60)
- 21** RS-232-C Connector (page 62)
- 22** Power Cord

Note Regarding the KEY PROTECT Switch


KEY PROTECT



This switch should normally be left at the ON position in order to prevent accidental setting changes.

- ON** : Control Input will be accepted, and play will take place in accord with the stipulated settings.(Play Mode)
- OFF** : Control Input will be ignored. Functions such as recording/editing can be performed.

CONNECTION EXAMPLE





GETTING STARTED


RECORDING

Getting Ready

- 1 Connect a microphone, cassette deck, or other device to this unit's input jack.



- 2 Push the POWER switch ON.



- 3 Insert a memory card (SRAM) into the MEMORY CARD A slot.

- * Slide the write protect switch on the memory card to the "OFF" position.
- * Recordings cannot be made directly to a FLASH card.

- 4 Switch OFF the KEY PROTECT switch.

The KEY PROTECT indicator will go out.

Formatting Memory Cards


Before using all new memory cards, as well as any that have previously been used with other equipment, you must "format" (initialize) them so that this unit is able to work with them.

Any time you insert an unformatted memory card into a MEMORY CARD slot, you will be presented with the display page where formatting is carried out.

```
CARD Format
CARD A | 512KBytes
```

- * Should you not wish to go ahead and format the card, remove the card at this point.

Press [ENTER] to begin formatting the card.



```
Formatting 10%
CARD A | 512KBytes
```

Once formatting has completed, the unit goes into the PLAY mode.

```
NO PHRASE
```


«IMPORTANT»

Never remove the memory card from the slot while it is being formatted.


Cards can be inserted into either the A or B MEMORY CARD slots for formatting.

Making a Recording


1 Set the unit to the recording mode.



Press the [REC MODE] button.
The button's indicator will light.



2 Select the type using the [Δ]/[▽] buttons.




The following 3 types of recording (Sampling rate) are available:

1. → 8.5 k : Provides the longest amount of recording time.
2. → 17 k : Provides standard recording.
3. → 22 k : Provides the most realistic recording.

2 Select the Phrase number.


Each item of audio material that you record is referred to as a "Phrase." Each Phrase is organized according to its assigned number.




Select the Phrase number into which you intend to record using [Δ]/[▽].

* Immediately after a card has been newly formatted, this number will be "001."


4 Enter recording standby.



While holding down [STOP], press the [START] button. The Level Meter will appear in the display.




3 Select the type of recording.



① Using the [▶] button, move the blinking cursor to Type.

5 Set the recording level.




Use the INPUT LEVEL knob to adjust the recording level. At the ideal level, the "■" should not light at all.




«IMPORTANT»

Always place the volume at "0" for whichever input (Mike or Line) you are not using at that time.

6 Start recording.




Press the **[START]** button, and recording will begin. Once recording begins, the readout for "PLAY TIME" will begin changing.




«**IMPORTANT**»

- Recording stops automatically as soon as the "REMAINING TIME" reaches "0."
- When the "REMAINING TIME" becomes 5 seconds and less, the readout under "REC" will indicate those remaining seconds.




7 Stop recording.




Press the **[STOP]** button to get the recording to stop, and have what was recorded stored onto the card.

8 Check what was recorded.




- ① Using the **[◀]** button, move the blinking cursor to PHRASE No.
- ② Select the Phrase (number) you wish to check using the **[△]**/**[▽]** buttons.
- ③ Press the **[START]** button to start playback. Press the **[STOP]** button to stop playback.



9 Steps 2 through 8 can be repeated as many times as necessary.

10 Finish up with the recording process.




- ① Press the **[EXIT]** button. The REC MODE indicator will go out.
- ② Switch ON the KEY PROTECT switch. The KEY PROTECT indicator will light, and the unit is placed in the PLAY mode.

This unit allows you to select the volume level that will used during actual playback, and allows you to specify an amount of delay before play for each of the Phrases(audio segments) that you have recorded. For information on how to make these settings, refer to page 20.


Monitoring Memory Cards (Monitor Mode)

Perform the steps below to listen to (monitor) the Phrases that have been recorded onto a memory card.

- 1 Insert a card containing your recorded material into a MEMORY CARD slot (either A or B).




- 4 Select the appropriate Memory Card slot (A or B).




Press the [◀] button to select between A/B.

- 2 Switch OFF the KEY PROTECT switch.




The indicator will go out.

- 5 Begin monitoring.




Press the [START] button to begin monitoring.
Press the [STOP] button when you are through.

- 3 Select the Phrase you wish to monitor.



Select the Phrase number using the [▲]/[▼] buttons.



- 6 Exit the procedure.

Switch ON the KEY PROTECT switch.
The KEY PROTECT indicator will light, and the unit is placed in the PLAY mode.


PLAYBACK (PLAY MODE)

The following explains how to have Phrases played back using control signals sent by an external device. When the KEY PROTECT switch is ON, the unit will be in the PLAY mode.

* Control signal: ON/OFF events which occur as a result of shorting or opening the Control Input terminal and connector.

Program Play

- With each reception of a control signal, the next item will be played.
 - When shipped, the unit is set up so that when control signals are input to the PROGRAM PLAY Input Terminals, Phrases 1 through 16 will be played in numerical order. (Phrases into which nothing has been recorded are ignored.)
- * Program Play is given priority over Direct Play.




● Program Play 1 & 2


After making settings for Program Play 1 & 2 (page 44), you can have up to a total of 2 patterns, and 100 Phrases be played.

- The selection between Program Play 1 & 2 is made by applying a control signal to the "EXCHANGE" terminal of the CONTROL IN/OUT Terminals.
- * When a control signal is input at "EXCHANGE," the unit will return to the first Phrases for both Program Play 1 & 2.
- When Program Play 2 has not been set, the unit will return to the first Phrase number for Program Play 1 when the control signal is applied to the "EXCHANGE" terminal.

- Program Play (2 patterns played)
- When Program 2 is set




- Program Play (Reset carried out)
- When Program 2 has not been set




- During play, play can be stopped by applying a control signal to "STOP."

• STOP Control



- When a control signal is consecutively input at "START," the unit will repeatedly carry out Program Play.

• Consecutive Play



Direct Play

The following explains how Phrases which have been assigned to channels 1 through 16 can be selected and played by means of control signals.

- Using control signals input to the CONTROL IN/OUT connector (CH 1—16), the Phrases which have been assigned to be played back for each channel can be played.
- In making the settings for Control In (page 46), you can select from 3 available modes: Normal Play, Last-In Play, and Sequence Play. (At the defaults, the unit uses Normal Play.)


● Normal Play.....

The channels are treated in accord with their order of priority, with the lowest number having the highest priority.

Ch. 1 > Ch. 2 > Ch. 3 > ... Ch. 16


- Should a control signal having high priority channel be received during playback, what was being played is interrupted, and the corresponding high-priority channel is given priority and is played.

• When a high-priority ch. control signal is received:




- Should a control signal having low priority channel be received during playback, that low-priority channel control signal is ignored.


• When a low-priority ch. control signal is received:



- If successive control signals specifying a channel that has a low priority are input, that low priority channel will start being played back only after channels having a higher priority have finished playing.




- When a control signal is consecutively applied, the material will be played repeatedly.




● Last-In Play

- When an other channel control signal is received during playback, the Phrase that was being played is terminated, and the Phrase which corresponds to the control signal that was received most recently is played.




- If consecutive control signals are input, the channel which has thus been successively requested will be played again after some other channel, for which more recent control signals have been received, has finished playing.



■ PLAYBACK (PLAY MODE)

● Sequence Play

Any control signals received during playback are placed in memory, and will be used to play their indicated requests in the order received once the currently playing material has finished.




● Stop

During play, play will be stopped when a control signal is applied to "STOP."

Ordinarily, all playback (whether it is Last-in or Sequence) will be stopped.

● STOP Control





ADVANCED FEATURES

■ CHANGING THE SETTINGS FOR PHRASES


Changes in (or registration of) the settings for the items below can be made with respect to the Phrases that you record.

Playback Level (LEVEL)

Determines the volume at which your Phrases will be played. (Ordinarily 100%)

Amount of Delay (DELAY)

The amount of time that is to pass from the moment a control signal is received from an external device until the Phrases actually begin playing. (Ordinarily "0" seconds.)



Control Output (see page 61)

Selects whether Control Output is ON or OFF, and sets the Offset Time. (The amount of time before Control Output begins operating after Phrases have played.) (Ordinarily OFF.)

Phrase Name

To make it convenient to recognize and organize your Phrases, each of them can be given a name which can contain up to 11 characters.


Once Phrases have been supplied with names, their name will be displayed when relevant (such as when in the Play mode).

```
PLAY MODE
A001 | TEST
```

※ Settings for the Play Volume, Delay, and Control Out will be valid only when the Key Protect switch is at ON (while in the Play mode).


1 Set the unit to the recording mode.

- Switch OFF the KEY PROTECT switch.
(The indicator will go out.)




- Press the [REC MODE] button.
(The indicator will light.)


2 Set the playback LEVEL.



- Using the [▶] button, move the blinking cursor to LEVEL.
- Set the level using the [Δ]/[▽] buttons. (10 to 100)




3 Set the amount of DELAY.




- Using the [▶] button, move the blinking cursor to DELAY.

- Set the delay using the [Δ]/[▽] buttons.(0 to 59sec.)



4 Select ON or OFF for CONTROL OUTPUT.




- Press the [▶] button to reach the next display page.



- Set it either ON or OFF using the [Δ]/[▽] buttons.

5 Set the OFFSET Time for CONTROL OUTPUT.




- Use the [▶] button to move the cursor.
- Make the setting using the [Δ]/[▽] buttons. (0 to 59 sec.)




■ CHANGING THE SETTINGS FOR PHRASES

6 Supply the Phrase name.



① Press the [▶] button to reach the next display page.




② Use the [◀]/[▶] buttons to move the blinking cursor, and input the desired characters by pressing the [▲]/[▼] buttons.

* **Available Characters:**


(space) ! # \$ % & ' () * + , - . /
0-9 : ; < = > ? @ A-Z [] ^ _ a-z
{ }

7 Save settings onto memory card.



Press the [ENTER] button and the settings will be stored onto memory card.

8 Finish up with this procedure.



① Press the [EXIT] button.

The REC MODE indicator will go out.

② Switch ON the KEY PROTECT switch.

The KEY PROTECT indicator will light, and the unit returns to the PLAY mode.

Deleting the Phrase Name

Carry out the steps below to delete a Phrase Name (clear away all existing characters so you start over again with a fresh name).

1) While you have the Phrase Name shown in the display, press the [EDIT] button.



* Press the [EDIT] button again, and you are taken to the page where you can supply a name for the Phrase.

2) Press the [ENTER] button, and the Phrase Name will be erased.


DELETING PHRASES

Use the following procedure to delete unneeded Phrases that have been recorded.

* Pattern Phrases (page 29) cannot be deleted.

1 Select the Phrase that is to be erased.


- Switch OFF the KEY PROTECT switch.
(The indicator will go out.)



- Press the **[REC MODE]** button.
(The indicator will light.)

- Select the Phrase number using the **[▲]**/**[▼]** buttons.

2 Get into the Rec Edit mode.




Press the **[EDIT]** button.

The EDIT indicator will light, and the next display page will appear.




3 Choose the Delete function.



Use the **[▲]**/**[▼]** buttons to select "PHRASE DELETE."



4 Carry out the deletion.




- Press the **[▶]** button. The Phrase you are about to delete, and the settings for it will be shown.

* A change to another Phrase number cannot be made.




- Press the **[ENTER]** button to delete the Phrase.

* Press the **[EDIT]** button to return to the recording mode.



5 Finish up with this procedure.



- ① Press the **[EXIT]** button.
The REC MODE indicator will go out.
- ② Switch ON the KEY PROTECT switch.
The KEY PROTECT indicator will light, and the unit returns to the PLAY mode.


COPYING PHRASES

The following procedure allows you to copy a Phrase to another Phrase location.

* Pattern Phrases (page 29) cannot be copied.


1 Select the Phrase which is to become the source for the copy.

- Switch OFF the KEY PROTECT switch. (Its indicator will go out.)



- Press the [REC MODE] button. (The indicator will light.)
- Select the Phrase number using the [Δ]/[▽] buttons.


2 Get into the Rec Edit mode.




Press the [EDIT] button. The EDIT indicator will light, and a display page within that mode will appear.




3 Choose the phrase copying function.




Use the [Δ]/[▽] buttons to select "PHRASE COPY."



4 Specify the destination of the copy.




- Press the [▶] button.
- Select the Phrase number using the [Δ]/[▽] buttons.



* Press the [▶] button to select between Memory Card A/B.

■ COPYING PHRASES


5 Carry out the Phrase copy.



Press the **[ENTER]** button and the Phrase will be copied.

- * Press the **[EDIT]** button, and you will be returned to the recording mode.

6 Finish up with this procedure.



- 1 Press the **[EXIT]** button.
The REC MODE indicator will go out.
- 2 Switch ON the KEY PROTECT switch.
The KEY PROTECT indicator will light, and the unit returns to the PLAY mode.


DELETING SILENT PORTIONS

The following procedure allows you to have any silent portions within a Phrase be deleted automatically.

NOTE Silent portions cannot be deleted from Pattern Phrases (page 29).
 This procedure can be used only if the silent portions deletion function has been set to OFF in the Sub-Menu (page 54).


1 Select the Phrase from which you wish silent portions to be deleted.

- Switch OFF the KEY PROTECT switch.
 (Its indicator will go out.)




- Press the [REC MODE] button.
 (The indicator will light.)
- Select the Phrase number using the [Δ]/[▽] buttons.


2 Get into the Rec Edit mode.




Press the [EDIT] button.
 The EDIT indicator will light, and the next display page will appear.




3 Choose the delete silence function.



Use the [Δ]/[▽] buttons to select "SILENCER."




4 Carry out the deletion.



- Press the [▶] button. The Phrase from which you are about to delete silent portions, and the settings for it will be shown.


* A change to another Phrase number cannot be made.




- Press the [ENTER] button.
 Any silent portions at the beginning and end of the Phrase will be deleted.

■ DELETING SILENT PORTIONS


* Press the **[EDIT]** button to return to the recording mode.



Once the silent portions have been deleted, the display will change as follows.



5 Finish up with this procedure.



- ① Press the **[EXIT]** button.
The REC MODE indicator will go out.
- ② Switch ON the KEY PROTECT switch.
The KEY PROTECT indicator will light, and the unit returns to the PLAY mode.

PATTERN PHRASES

Once you have a number of Phrases recorded, they can be joined together to form another kind of Phrase, a "Pattern Phrase" which you can also store in memory.

This feature can be conveniently used when you need to have a Phrase repeated a number of times -- simply join the same Phrase repeatedly. Also, through the well-planned use of Pattern Phrases, you can reduce the overall amount of data you need to store.


- * Up to a maximum of 100 Pattern Phrases can be registered.
- * Whatever setting for the Play Volume that has been made for each of the Phrases will remain in effect.
- * Any Phrase that has been assigned for use in a Pattern Phrase will have a "P" shown for its "Type."

PLAY MODE				
A001	P	10	00	---
PHRASE No.	TYPE	LEVEL	DELAY	PLAY TIME

«NOTE» A Pattern Phrase can only use Phrases which reside on the same card as it does. Pattern Phrases cannot be joined to other Pattern Phrases.

1 Select the editing mode.


- ① Switch OFF the KEY PROTECT switch.
(The indicator will go out.)



- ② Press the [EDIT] button.
(Its indicator will light.)
- ③ Use the [Δ]/[▽]/[◀]/[▶] buttons to select "EDIT."

EDIT	SYSTEM
COPY	SUB_MENU
PHRASE No.	TYPE LEVEL DELAY PLAY TIME


2 Choose the Pattern Phrase function.



- ① Press the [ENTER] button.
- ② Use the [Δ]/[▽] buttons to select "PATTERN PHRASE."


EDIT	
1	PATTERN PHRASE
PHRASE No.	TYPE LEVEL DELAY PLAY TIME

3 Select the Phrase that is to be made a Pattern Phrase.



- ① Press the [▶] button.
- ② Select the Phrase number using the [▲]/[▼] buttons.


* Empty Phrase numbers and Pattern Phrases are shown in the display.




Deleting Pattern Phrases

Perform the steps below to delete the currently displayed Pattern Phrase.

- 1) Press the [EDIT] button.



- 2) Press the [ENTER] button, and the Pattern Phrase will be deleted.




* To cancel the Pattern Phrase Delete, press the [EDIT] button.


Displaying the Play Time for a Pattern Phrase

Perform the steps below to check the play time for the currently displayed Pattern Phrase.


- 1) Press the [REC MODE] button.




- 2) Press the [EDIT] button, and you are returned to the page you were in before.




4 Set the order in which they are to play.




- ① Use the [▶] button to move the blinking cursor.
- ② Make the setting using the [▲]/[▼] buttons.




5 Select a Phrase to include in the pattern.




- 1 Use the [▶] button to move the blinking cursor.
 - 2 Select the Phrase numbers to include using the [▲]/[▼] buttons.
- * Only the numbers for Phrases which have recorded material in them will be shown.




6 Set the amount of time to pause before the next Phrase.



- 1 Use the [▶] button to move the blinking cursor.
- 2 Set the amount of pause using the [▲]/[▼] buttons.




7 Return to Step 4.



Press the [◀] button to go back.


8 Repeat Steps 4 through 7 until you have joined all the Phrases you wish to include.

9 Store the Pattern Phrase.



Press the [ENTER] button, and the settings for the Pattern Phrase are stored in memory.

10 Finish up with this procedure.




- 1 Press the [EXIT] button.
The REC MODE indicator will go out.
- 2 Switch ON the KEY PROTECT switch.
The KEY PROTECT indicator will light, and the unit returns to the PLAY mode.

ERASING MEMORY CARD DATA


The procedure below will erase all data stored on a memory card.

1 Select the editing mode.


- Switch OFF the KEY PROTECT switch.
(The indicator will go out.)



- Press the **[EDIT]** button.
(Its indicator will light.)
- Use the **[△]/[▽]/[◀]/[▶]** buttons to select "EDIT."




2 Choose the card erasure function.




- Press the **[ENTER]** button.
- Use the **[△]/[▽]** buttons to select "CARD DELETE."




3 Select the memory card that is to be erased.



- Press the **[▶]** button.
- Select which memory card to erase (A or B) using the **[△]/[▽]** buttons.




4 Carry out the erasure.



Press the **[ENTER]** button.
All Phrases contained on the memory card will be erased.

5 Finish up with this procedure.




- ① Press the **[EXIT]** button.
The EDIT indicator will go out.
- ② Switch ON the KEY PROTECT switch.
The KEY PROTECT indicator will light, and the unit returns to the PLAY mode.


FORMAT OF MEMORY CARDS

1 Select the editing mode.


- 1) Switch OFF the KEY PROTECT switch.
(The indicator will go out.)




- 2) Press the [EDIT] button.
(Its indicator will light.)
- 3) Use the [▲]/[▼]/[◀]/[▶] buttons to select "EDIT."




2 Choose the card formatting function.




- 1) Press the [ENTER] button.
- 2) Use the [▲]/[▼] buttons to select "CARD FORMAT."




3 Select the memory card slot.



- 1) Press the [▶] button.
- 2) Select the targeted card slot (A or B) using the [▲]/[▼] buttons.




4 Select the capacity at which to format.




- 1) Use the [▶] button to move the cursor.
- 2) Set the capacity using the [▲]/[▼] buttons.


- * You can also format a card at a capacity which is smaller than the allowable capacity of the card. Doing so can be useful when wishing to make copies of the memory card.



5 Carry out the formatting.




Press the **[ENTER]** button, and the card will be formatted.



«**IMPORTANT**»

Never remove a memory card while formatting is in progress.

6 Finish up with this procedure.



- ① Press the **[EXIT]** button.
The EDIT indicator will go out.
- ② Switch ON the KEY PROTECT switch.
The KEY PROTECT indicator will light, and the unit returns to the PLAY mode.


GIVING CARDS A NAME

Each memory card can be supplied with a name that consists of 8 characters or less. By giving cards a name, you will much easily be able to distinguish among them.

* The card name will be displayed for about 3 seconds whenever a card is inserted.


1 Select the editing mode.

- Switch OFF the KEY PROTECT switch.
(The indicator will go out.)




- Press the **[EDIT]** button.
(Its indicator will light.)


- Use the **[△]/[▽]/[◀]/[▶]** buttons to select "EDIT."




2 Choose the card naming function.




- Press the **[ENTER]** button.
- Use the **[△]/[▽]** buttons to select "CARD NAME."




3 Select the memory card slot.




- Press the **[▶]** button.
- Select the relevant card slot (A or B) using the **[△]/[▽]** buttons.



4 Specify the card name.



- Press the **[▶]** button.



- While using the **[◀]/[▶]** buttons to move the cursor, input the desired characters by pressing the **[△]/[▽]** buttons.

* **Available Characters:**

(space)! # \$ % & ' () 0-9 : ; < =
> ? @ A-Z _



Deleting the Card Name


Carry out the steps below to delete a Card Name (clear away all existing characters to allow space for a new name).

- 1) While you have the Card Name shown in the display, press the **[EDIT]** button.




- * Press the **[EDIT]** button again, and you are taken to the page where you can supply a new name for the card.
- 2) Press the **[ENTER]** button to delete the Card Name.

5 Finalize the card name.



Press the **[ENTER]** button, and the card name will be registered.

6 Finish up with this procedure.



- ① Press the **[EXIT]** button.
The EDIT indicator will go out.
- ② Switch ON the KEY PROTECT switch.
The KEY PROTECT indicator will light, and the unit returns to the PLAY mode.

MAKING COPIES OF SRAM CARDS


The procedure below allows you to make a copy of one SRAM card onto another. The card contained in slot A is copied to the card in slot B.

«IMPORTANT»

- You must insert the source card in MEMORY CARD A slot, and the card onto which to make the copy into the MEMORY CARD B slot.
- **Never attempt to remove the cards while the copy is being made.**
- Copies can only be made between cards which both have the same capacity.
- You need to use the FLASH COPY function to copy FLASH cards.


1 Select the copying mode.

- 1 Switch OFF the KEY PROTECT switch.
(The indicator will go out.)




- 2 Press the [EDIT] button.
(Its indicator will light.)


- 3 Use the [△]/[▽]/[◀]/[▶] buttons to select "COPY."




2 Choose the SRAM card copying function.



- 1 Press the [ENTER] button.
- 2 Use the [△]/[▽] buttons to select "SRAM COPY."




3 Carry out the SRAM copying.




- 1 Press the [▶] button.

- 2 Press the [ENTER] button, and the card will be copied.



4 Finish up with this procedure.



- 1 Press the [EXIT] button.
The EDIT indicator will go out.

- 2 Switch ON the KEY PROTECT switch.
The KEY PROTECT indicator will light, and the unit returns to the PLAY mode.

MAKING COPIES OF FLASH CARDS


The procedure below allows you to make a copy of an SRAM or FLASH card onto a FLASH card.

«IMPORTANT»


- You must insert the source card in MEMORY CARD A slot, and the card onto which to make the copy into the MEMORY CARD B slot.
- **Never attempt to remove the cards while the copy is being made.**
- Copies can only be made between cards which both have the same capacity.

1 Select the copying mode.


- ① Switch OFF the KEY PROTECT switch.
(The indicator will go out.)




- ② Press the [EDIT] button.
(Its indicator will light.)
- ③ Use the [△]/[▽]/[◀]/[▶] buttons to select "COPY."




2 Choose the FLASH card copying function.




- ① Press the [ENTER] button.
- ② Use the [△]/[▽] buttons to select "FLASH COPY."



3 Carry out the FLASH card copying.




- ① Press the [▶] button.
- ② Press the [ENTER] button, and the card will be copied.



- * Please be prepared to wait a considerable amount of time, since FLASH cards require more time than others to copy.

4 Finish up with this procedure.



- ① Press the [EXIT] button.
The EDIT indicator will go out.
- ② Switch ON the KEY PROTECT switch.
The KEY PROTECT indicator will light, and the unit returns to the PLAY mode.

SYSTEM SETTINGS

Settings which determine the manner in which Phrases will be played in the Play mode, and other settings related to Control Input are referred to as "System Data."

System Data can be of any of the following 4 types. All of this data can be stored on memory cards.


- The playing order for Program Play.
- The Phrase assignments made for the channels (1—16).
- How play should take place during Direct Play.
- Setting for the Power On mode.

Setting the Target for Storage of System Data


Perform the following to select whether the System Data is to be stored in internal memory or on a memory card. The target that has been set here will be used to store all System Data.

1 Select the system mode.


- Switch OFF the KEY PROTECT switch.
(The indicator will go out.)




- Press the [EDIT] button.
(Its indicator will light.)
- Use the [△]/[▽]/[◀]/[▶] buttons to select "SYSTEM."




2 Select SYSTEM SELECT.




- Press the [ENTER] button.
- Use the [△]/[▽] buttons to select "SYSTEM SELECT."




3 Select the target for storage of system data.



- ① Press the [▶] button.
- ② Use the [▲]/[▼] buttons to select "AR-1000", "CARD A" or "CARD B."




4 Finalize the choice for the target.



Press the [ENTER] button, and the selected target is set.

5 Finish up with this procedure.



- ① Press the [EXIT] button.
The EDIT indicator will go out.
- ② Switch ON the KEY PROTECT switch.
The KEY PROTECT indicator will light, and the unit returns to the PLAY mode.

During play, all system data will be read from the storage location which has been set here. If there is no system data available at the specified storage location, the unit will read the data it finds at some other location.

● Setting the Playing Order for Program Play


The following procedure is used to decide on the playing order that Phrases will follow for Program Play. Program Play provides for 2 patterns (Program Play 1 & 2). A combined total of 100 Phrases can be registered.

The factory defaults are as follows :


- Program Play 1 Phrase Nos. 001—016 are registered on memory card A.
- Program Play 2 No Phrases are registered.

1 Select the system mode.


- 1 Switch OFF the KEY PROTECT switch.
(The indicator will go out.)





- 2 Press the [EDIT] button.
(Its indicator will light.)
- 3 Use the [▲]/[▼]/[◀]/[▶] buttons to select "SYSTEM."




2 Select PROGRAM PLAY.




- 1 Press the [ENTER] button.
- 2 Use the [▲]/[▼] buttons to select "PROGRAM PLAY 1" or "PROGRAM PLAY 2."




3 Select the playing order.




- ① Press the [▶] button.
- ② Use the [▲]/[▼] buttons to set the playing order.




4 Select the Phrases.



- ① Use the [▶] button to move the cursor.
- ② Select the Phrase numbers to be played, in accord with the order set in ③, using the [▲]/[▼] buttons.




* Phrases which have not yet been recorded will also be displayed.



* You can choose among memory cards A, B, & C by pressing the [▶] button. Note, however, that card C refers to an expansion card, and will not be a valid choice if using this unit alone.


5 Return to Step ③.



Press the [◀] button to go back.


6 Repeat Steps ③ through ⑤ as many times as necessary.

7 Store the playing order.



Press the [ENTER] button, and the playing order is stored in memory.

8 Finish up with this procedure.



- ① Press the [EXIT] button.
The EDIT indicator will go out.
- ② Switch ON the KEY PROTECT switch.
The KEY PROTECT indicator will light, and the unit returns to the PLAY mode.


Assigning Phrases to Control Input Channels

The following procedure is used to assign Phrases to Control Input Channels 1 through 16. You will then be able to directly control the play of up to 16 Phrases by means of the Control In/Out connectors.


At the factory defaults, the unit is set so Phrases 001—016 are assigned to channels 1—16 on memory card A.

1 Select the system mode.


- 1 Switch OFF the KEY PROTECT switch. (The indicator will go out.)




- 2 Press the [EDIT] button. (Its indicator will light.)
- 3 Use the [△]/[▽]/[◀]/[▶] buttons to select "SYSTEM."




2 Select the Control Channel function.




- 1 Press the [ENTER] button.
- 2 Use the [△]/[▽] buttons to select "CONT.CHANNEL."




3 Set the channel.




- 1 Press the [▶] button.
- 2 Use the [△]/[▽] buttons to select the channel.




4 Specify the Phrase.



- 1 Use the [▶] button to move the cursor.
- 2 Select the Phrase number using the [△]/[▽] buttons.




5 Return to Step **3**.



Press the [◀] button to go back.


6 Repeat Steps **3** through **5** as many times as necessary.

7 Store the settings.



Press the [ENTER] button, and your Phrase assignments to Control Input channels will be stored in memory.

8 Finish up with this procedure.



- ① Press the [EXIT] button.
The EDIT indicator will go out.
- ② Switch ON the KEY PROTECT switch.
The KEY PROTECT indicator will light, and the unit returns to the PLAY mode.


● Setting How Play Should Take Place During Direct Play

Perform the steps below to make your choice for how play should take place during direct play (the "Type"). The selections available are: Normal, Last-In, Sequence, and RS-232-C.

* When shipped, the unit was set to use Normal Play.


1 Select the system mode.

- Switch OFF the KEY PROTECT switch.
(The indicator will go out.)




- Press the **[EDIT]** button.
(Its indicator will light.)


- Use the **[△]/[▽]/[◀]/[▶]** buttons to select "SYSTEM."




2 Select the Control Input function.




- Press the **[ENTER]** button.
- Use the **[△]/[▽]** buttons to select "CONT.IN."



3 Select the Type.




- Press the **[▶]** button.
- Use the **[△]/[▽]** buttons to select from NORMAL/ LAST-IN/SEQUENCE/RS-232-C.



«NOTE»


If you select RS-232-C all the other types of Control Input will be ignored.

4 Store the Type.



Press the **[ENTER]** button, and the Type is registered in memory.

5 Finish up with this procedure.



- ① Press the **[EXIT]** button.
The EDIT indicator will go out.
- ② Switch ON the KEY PROTECT switch.
The KEY PROTECT indicator will light, and the unit returns to the PLAY mode.

● Setting for the Power On Mode

The following explains the selection available for the manner in which the unit will be set to handle Program Play each time power is turned on (Power On Mode). Two Power On modes are available.

* When shipped, the unit was set to "AUTO."

AUTO

Program Play will start upon input of a Program Play signal.
If power is turned OFF then ON again, the unit will return to Program Play No. 1.

PGM	PLAY1		AUTO
001	A001		1 80 00

The Program Play Number can be changed using the [△]/[▽] buttons. Press the [ENTER] button and the Program Play Number will change.

«NOTE» Changes in the Program Play Number must be made before a Program Play signal arrives.

MANUAL

Unless the Program Play Number is changed and the [ENTER] button is pressed, a Direct Play signal is input, or a **Reset signal** (*see below) is input, play will not take place when a Program Play signal arrives.

This mode can be used to prevent the playing of Phrases at incorrect times, as the result of discrepancies between the actual time and the Phrase order (caused by a power failure, for example) while this unit is used in tandem with a timing device (such as the Roland FG-1000). Since in order for something to be played a change to a specific Program Play Number must be made even after power has been turned off momentarily, Phrases will not be played at inappropriate times.

If power is turned OFF then ON again, the unit will return to Program Play No. 1.


PGM	PLAY1		MANUAL
001	A001		1 80 00

The Program Play Number can be changed using the [△]/[▽] buttons. Press the [ENTER] button and the Program Play Number will change.


* **Reset Signal** : A control signal which is input to the Program Play Input Terminals for a duration of more than 30 seconds.

1 Select the system mode.


- ① Switch OFF the KEY PROTECT switch.
(The indicator will go out.)




- ② Press the [EDIT] button.
(Its indicator will light.)
- ③ Use the [△]/[▽]/[◀]/[▶] buttons to select "SYSTEM."




2 Select the Power On Mode.




- ① Press the [ENTER] button.
- ② Use the [△]/[▽] buttons to select "POWER ON."



3 Set the mode to either Auto or Manual.




- ① Press the [▶] button.
- ② Use the [△]/[▽] buttons to switch between AUTO/MANUAL.




AUTO : Automatic Mode
MANUAL : Manual Mode

4 Store the setting for the Power On Mode.



Press the [ENTER] button, and your choice for the Power On Mode is registered in memory.

5 Finish up with this procedure.



- ① Press the [EXIT] button.
The EDIT indicator will go out.
- ② Switch ON the KEY PROTECT switch.
The KEY PROTECT indicator will light, and the unit returns to the PLAY mode.

■ CONFIGURATION (SUB-MENU)


The group of settings used to configure the unit to suit the setup you have in mind is located with the "SUB-MENU."

● Choice for Play Monitoring

Perform the steps below to switch between either the internal speaker or the BALANCED OUTPUT jack as the path to be used for output of audio while in the Monitor mode.

1 Select the Sub - Menu.


- Switch OFF the KEY PROTECT switch.
(The indicator will go out.)



- Press the [EDIT] button.
(Its indicator will light.)
- Use the [Δ]/[∇]/[◀]/[▶] buttons to select "SUB_MENU."

EDIT	SYSTEM
COPY	SUB_MENU
PHRASE No.	TYPE LEVEL DELAY PLAY TIME


2 Select the Play Monitor function.




- Press the [ENTER] button.
- Use the [Δ]/[∇] buttons to select "PLAY MONITOR."

SUB_MENU				
1		PLAY	MONITOR	
PHRASE No.	TYPE	LEVEL	DELAY	PLAY TIME

3 Select the path for the output.




- ① Press the [▶] button.
- ② Use the [▲]/[▼] buttons to make the selection.



INTERNAL : Audio will be output from the unit's internal speaker.


BALANCED : Audio will be output from the unit's BALANCED OUTPUT jack.
Connect these outputs with amp/ speakers.

4 Store the selected output path.



Press the [ENTER] button, and the specified output path is registered in memory.

5 Finish up with this procedure.




- ① Press the [EXIT] button.
The EDIT indicator will go out.
- ② Switch ON the KEY PROTECT switch.
The KEY PROTECT indicator will light, and the unit returns to the PLAY mode.

● Choice for Recording Monitoring


Perform the steps below to switch between either the internal speaker or the BALANCED OUTPUT jack as the path to be used for output of audio while in the Recording mode.

1 Select the Sub - Menu.


- 1 Switch OFF the KEY PROTECT switch.
(The indicator will go out.)




- 2 Press the [EDIT] button.
(Its indicator will light.)
- 3 Use the [△]/[▽]/[◀]/[▶] buttons to select "SUB_MENU."




2 Select the Recording Monitor function.



- 1 Press the [ENTER] button.
- 2 Use the [△]/[▽] buttons to select "REC MONITOR."



3 Select the path for the output.




- 1 Press the [▶] button.
- 2 Use the [△]/[▽] buttons to make the selection.



INTERNAL : Audio will be output from the unit's internal speaker.


BALANCED : Audio will be output from the unit's BALANCED OUTPUT jack.
Connect these outputs with amp/speakers.

4 Store the selected output path.



Press the **[ENTER]** button, and the specified output path is registered in memory.

5 Finish up with this procedure.




- ① Press the **[EXIT]** button.
The EDIT indicator will go out.
- ② Switch ON the KEY PROTECT switch.
The KEY PROTECT indicator will light, and the unit returns to the PLAY mode.

● Setting the Silent Portions Deletion Function


Perform the steps below to choose whether the silent portions deletion function should be ON or OFF.
 When ON, this function will automatically delete all of the useless silent portions that can often be introduced during recording. This function works on the silence that occurs at the very beginning, when recording had started, yet the actual audio had not yet begun; and at the end, where the subject sound had finished, but recording had not yet been stopped.

1 Select the Sub - Menu.


- ① Switch OFF the KEY PROTECT switch.
(The indicator will go out.)




- ② Press the [EDIT] button.
(Its indicator will light.)
- ③ Use the [△]/[▽]/[◀]/[▶] buttons to select "SUB_MENU."




2 Select the silent portions deletion function.



- ① Press the [ENTER] button.
- ② Use the [△]/[▽] buttons to select "SILENCER."




3 Choose to have the silent portions deletion function at either ON or OFF.



- ① Press the [▶] button.
- ② Use the [△]/[▽] buttons to switch between ON/OFF.




4 Store the setting for the silent portions deletion function.



Press the [ENTER] button, and the ON/OFF choice is registered in memory.

5 Finish up with this procedure.



- ① Press the **[EXIT]** button.
The EDIT indicator will go out.
- ② Switch ON the KEY PROTECT switch.
The KEY PROTECT indicator will light, and the unit returns to the PLAY mode.


● Setting the Baud Rate for RS-232-C Communications

Perform the steps below to set the baud rate to be used when employing the RS-232-C connector for control.


* When shipped, the unit was set to 9,600 bps.

1 Select the Sub - Menu.


- Switch OFF the KEY PROTECT switch.
(The indicator will go out.)




- Press the [EDIT] button.
(Its indicator will light.)
- Use the [Δ]/[▽]/[◀]/[▶] buttons to select "SUB_MENU."




2 Select RS - 232C.



- Press the [ENTER] button.
- Use the [Δ]/[▽] buttons to select "RS - 232C."




3 Select the Baud Rate.




- Press the [▶] button.
- Use the [Δ]/[▽] buttons to select the baud rate.

Baud Rate Choices: 4,800, 9,600 bps




4 Store the Baud Rate setting.



Press the [ENTER] button to register the Baud Rate in memory.

5 Finish up with this procedure.




- ① Press the **[EXIT]** button.
The EDIT indicator will go out.
- ② Switch ON the KEY PROTECT switch.
The KEY PROTECT indicator will light, and the unit returns to the PLAY mode.

● Using the LINE IN MUTE Feature


When in the Play mode, the audio or the like can be input to the LINE IN jacks when you wish to have that audio output from the BALANCED OUTPUT jack.

During times when Phrases are played back, audio that is input to the LINE IN jacks will be mixed before output with the material this unit plays back. By selecting to use the **LINE IN MUTE feature**, you can have the volume of the audio arriving at LINE IN automatically be turned down at the moment that the playback of a Phrase begins. It is then returned to its original volume after the Phrase has completed.




1 Select the Sub - Menu.


- ① Switch OFF the KEY PROTECT switch.
(The indicator will go out.)




- ② Press the [EDIT] button.
(Its indicator will light.)
- ③ Use the [△]/[▽]/[◀]/[▶] buttons to select "SUB_MENU."




2 Select the MUTE Feature.



- ① Press the [ENTER] button.
- ② Use the [△]/[▽] buttons to select "LINE IN MUTE."




3 Select ON or OFF for MUTE.




- ① Press the [▶] button.
- ② Set it either ON or OFF using the [▲]/[▼] buttons.

«NOTE»


When at OFF, the volume of the audio arriving at LINE IN will NOT be turned down when playback of a Phrase begins.



4 Select the volume that applies while muted.




- ① Press the [▶] button.
- ② Using the [▲]/[▼] buttons, specify the volume level for the audio arriving at LINE IN (0—80%).



«NOTE»


When set to "0," the audio arriving at LINE IN will not sound at all while a Phrase is being played back.

5 Register the setting for the MUTE feature.




Press the [ENTER] button, and the setting for the MUTE feature will be placed in effect.

6 Finish up with this procedure.




- ① Press the [EXIT] button.
The EDIT indicator will go out.
- ② Switch ON the KEY PROTECT switch.
The KEY PROTECT indicator will light, and the unit returns to the PLAY mode.

ABOUT THE CONTROL IN/OUTS



Specifications of the CONTROL IN/OUT Connector

Pin No.	Signal name	Pinout
1	CH 1	
2	CH 2	
3	CH 3	
4	CH 4	
5	CH 5	
6	CH 6	
7	CH 7	
8	CH 8	
9	Common (GND)	
10	CH 9	
11	CH 10	
12	CH 11	
13	CH 12	
14	CH 13	
15	CH 14	
16	CH 15	
17	CH 16	
18	Common (GND)	
19	Start	
20	Stop	
21	Shift	
22	Busy Output	
23	Busy Output	
24	Control Output	
25	Control Output	



● Control Input

Start signals from external devices should be ON/OFF events that short or open the Control Input terminals and connector.


The start signal (input signal) needs to be sustained for at least 100ms.

- * Program Play is given precedence over Direct Play.
- * When using RS-232-C all other forms of Control Input become invalid.

● Control Output

Busy Output


Busy Output is output which occurs when the contacts are closed during play. It can be used to control an external amplifier, etc.



- Busy Output is output from both the CONTROL IN/OUT Terminals and the CONTROL IN/OUT Connector.
- The maximum load sustainable by the contacts is DC30 V, 5 A.
- Busy Output will occur even during a period of pause.

Control Output

Control Output is output which occurs when the contacts are closed after play. It can be used to control an external device after play has taken place.



- Control Output is output from both the CONTROL IN/OUT Terminals and the CONTROL IN/OUT Connector.
- The settings for Control Output should be made as explained on page 20.
- The maximum load sustainable by the contacts is DC30 V, 5 A.
- The make time is 5 seconds.

● RS-232-C

A personal computer can be used to control this unit.

«Protocol»

Transmission method : Start – stop transmission (asynchronous),
full-duplex
Baud rate : 4,800 / 9,600 bps
Parity : None
Data : 8 bits
Stop bit : 1 bit
Character code : ASCII

«Connector Specifications»

Pin No.	Signal name	Pinout
1	FG	
2	TXD	
3	RXD	
4	RTS	
5	CTS	
6	DSR	
7	GND	
8	DCO	
9	NC	
10	NC	
11	NC	
12	NC	
13	NC	
14	NC	
15	NC	
16	NC	
17	NC	
18	NC	
19	NC	
20	DTR	
21	NC	
22	NC	
23	NC	
24	NC	
25	NC	

«Connecting Cables» Most commercially available RS-232-C cables (reverse) are acceptable.

1. Command Format

- All commands consist of the STX character (02H) in combination with a two-character identifier.
- There are two types of commands; those that carry parameters, and those that do not.

Type 1 Commands Carrying No Parameters

«Ex.» Command ;

- The semicolon is appended to commands, and serves as the delimiter between them.

Type 2 Commands Requiring Parameters

«Ex.» Command : Parameter, Parameter,..... ;

- A colon is used as the separator between the command and its parameters.
- A comma is placed as a separator between parameters.
- A semicolon is placed at the end of the command string, and serves as the delimiter.

2. Commands

External → AR-1000

PA

Function Specifies Phrases to play

Syntax PA : P_No , P_No.....P_No

P_No : Phrase Number (4 bytes)
[A001—B250]

Example [STX] + PA : A002 : 28 ;

(Play Phrase #2 on card A)

Note 100 is the max. number of Phrases specifiable

PL

Function Starts play

Syntax PL ;

Example [STX] + PL ;

Note Ordinarily starts with A001 if no Phrase has been specified for play (PA command)

ST

Function Stops play

Syntax ST ;

Example [STX] + ST ;

LP

Function Performs loop play

Syntax LP ;

Example [STX] + LP ;

LS

Function Stops loop play

Syntax LS ;

Example [STX] + LS ;

Note Although loop play is stopped, play itself is not

AC

Function Checks the Active status of this unit

Syntax AC ;

Example [STX] + AC ;

AR-1000 → External

AC

Function Provides response to external AC requests

Syntax AC : ST, P_No ;

ST : Current status (1 byte)

0 : Play in progress

1 : Recording in progress/
in recording standby

P : Play in progress

P_No. : Phrase Number (4 bytes)

[A001—B250]

Example **[STX]** + AC : P, B120 ;

Phrase #120 on card B currently being played →
AC command

ACK

Function Provides response to ordinary status checks, and
acknowledges reception of commands

Responds upon reception of AC commands (with
Play stopped)

Syntax ACK(06H)

Returns only the control code, 06H

Example "06H"

ER

Function Output when an error has occurred

Syntax ER : E_No ;

E_No : Error Number (1 byte)

0 : Syntax Error

The syntax is incorrect

1 : Illegal Operation

The command cannot executed

e.g.) Memory card is not inserted

Example **[STX]** + ER : 1 ;

Note When this command is created, all the other
commands will be ignored

CC

Function Provides output of the insertion status

Syntax CC : a,b ;

a : Insertion status of Card A

0: Not inserted

1: Inserted

b : Insertion status of Card B

0: Not inserted

1: Inserted

Example **[STX]** + CC : 0,1 ;

Note Generated automatically by the unit

■ ERROR MESSAGES

When a mistake in an operational procedure has been made, or the unit is unable to carry out a procedure properly, an Error Message will appear in the display. Should this occur, refer to the information below and perform the indicated remedy.

INSERT CARD

Cause : A memory card is not properly inserted in a slot.

Remedy : Insert a card into the slot.

RESERVED FOR
PATTERN PHRASE

Cause : A Phrase being used by a Pattern Phrase cannot be deleted or overwritten.

Remedy : You need to first delete the Phrase from the Pattern Phrase it belongs to, then delete / overwrite it.

NOT USED CARD A

A or B

Cause : A card that is unknown to the AR-1000 has been inserted.

Remedy : Switch to a card that the AR-1000 recognizes card usable on the AR-1000.

WRITE PROTECT

Cause : The Write Protect switch on the memory card is set to the "ON" position.

Remedy : Slide the Write Protect switch to the "OFF" position.


CARD A
BATTERY LOW

A or B

Cause : The memory card's backup-use battery has become depleted.

Remedy : Refer to the manual supplied with the memory card and replace its battery.

SCALE DIAGRAM OF EXTERIOR



SPECIFICATIONS

● Recording Format

ADPCM

● Maximum Recording Time

1960 sec

(Sampling rate: 8.5 kHz and 4M memory card x 2)

● Maximum Number of Phrase Recordable

500 phrases

(512k Bytes or more memory card x 2)

● Play mode

Program play : 2 pattern, Max 100 phrase

Direct play : 16 channels, 3 mode

(Normal, last-In, Sequence)

RS-232C

Continuous play phrase : Max 100 phrase

Play phrase : Max 500 phrase

● Sampling Rate

8.5, 17, 22 [kHz]

● Inputs

MIC Input(Front Panel) : 1

Input Impedance : 3k Ω

Nominal Input Level : - 50 dBm

Input Sensitivity : - 60dBm

Recommended

Source Impedance : 600 Ω or less

LINE Inputs(Rear Panel) : STEREO x 1

Input Impedance : 10 k Ω

Nominal Input Level : 0 dBm

Input Sensitivity : - 10dBm

Recommended

Source Impedance : 600 Ω or less

● Outputs

LINE Output : Balanced Out x 1

Output Impedance : 150 Ω

Nominal Output Level : 0 dBm

Non-clip Max. Output : +12dBm

(Balanced Output 600 Ω loaded.)

Recommended

Load Impedance : 600 Ω or less

[Control Ins and Outs]

● Control Ins

Number of Inputs : 3

● Program Play Input Jack : Program Play (Start)

● Control Ins and Outs Terminal

Play mode : Program Play

(Start, Stop, Exchange)

Trigger Signal Format : On, Off (Open, Close)

Current ratings : DC 24 V, 0.5 A or more

Control Ins and Outs Jack

Play mode:

1. Program Play (Start, Stop, Exchange)

2. Direct Play (16 Channels)

Trigger Signal Format : On, Off (Open, Close)

Current ratings : DC 24 V, 0.5 A or more

● Control Outs

Number of Outputs : 2

● Control Ins and Outs Terminal

1.Busy (During play ON)

2.Control Out

Signal Format : On, Off (Open, Close)

Current ratings : DC 30 V, 5 A

Control Ins and Outs Jack

1.Busy (During play ON)

2.Control Out

Signal Format : On, Off (Open, Close)

Current ratings : DC 30 V, 5 A

Busy (During play ON)

Control Out(16 Channels)

● RS-232-C

Transmission method : Start-Stop synchronous system

(Asynchronous)

Duplex data transmission

Baud rate : 4800/9600 bps

Parity : none

Data bit : 8 bit

Stop bit : 1 bit

Code : ASCII

■ SPECIFICATIONS

[Hardware]

● Display

1 line 20 character (Backlit LCD)

● Indicator

REC Mode Indicator
Edit Mode Indicator
Key Protect Indicator

● Controllers

Start Button
Stop Button
Item Select Button (x 2)
Inc/Dec Button (x 2)
REC Mode Button
Edit Mode Button
Enter Button
Exit Button
Input Volume Knob
Output Volume Knob
Key Protect Switch
Power Switch

● Connectors

LINE Input Jacks (L, R)
Balanced Output Jack
Program Play Input Jack
Control Ins and Outs Terminal :
Terminal Block with M3 bolts
(7.62mm between terminals)
Control Ins and Outs Jack :
D subminiature 25 Pin Connector
(Socket type)
RS-232-C Jack :
D subminiature 25 Pin Connector
(Pin type)

● Power Supply

AC 117V, AC 230V or AC 240V

● Power Consumption

15W (AC 117V/230V/240V)

● Dimensions

482 (W) x 300 (D) x 44 (H) mm
19 (W) x 11-13/16 (D) x 1-3/4 (H) inches
(EIA-1U rack mount type)

● Weight

4.1 kg / 9lbs 1oz

● Supplied Accessories

Owner's Manual
Cable
D subminiature 25 Pin connector (for Control IN/OUT Jack)

※ The specifications for this product are subject to change without prior notice.

1. The first part of the text discusses the importance of maintaining accurate records of all transactions and activities. It emphasizes that proper record-keeping is essential for financial transparency and accountability, particularly in the context of public administration or government operations. The text suggests that without reliable records, it becomes difficult to track expenditures, assess performance, and ensure that resources are being used effectively and ethically.

Information

When you need repair service, call your local Roland Service Station or the authorized Roland distributor in your country as shown below.

U. S. A.

Roland Corporation US
7200 Dominion Circle
Los Angeles, CA.
90040-3647, U. S. A.
☎ (213)685 - 5141

CANADA

Roland Canada Music Ltd.
(Head Office)
5480 Parkwood
Richmond B. C., V6V 2M4
CANADA
☎ (604)270 - 6626

Roland Canada Music Ltd.
9425 Transcanadienne
Service Rd. N., St Laurent,
Quebec H4S 1V3,
CANADA
☎ (514)335 - 2009

Roland Canada Music Ltd.
346 Watline Avenue,
Mississauga, Ontario L4Z
1X2, CANADA
☎ (416)890 - 6488

AUSTRALIA

Roland Corporation
(Australia) Pty. Ltd.
(Head Office)
38 Campbell Avenue
Dee Why West, NSW 2099
AUSTRALIA
☎ (02)982 - 8266

Roland Corporation
(Australia) Pty. Ltd.
(Melbourne Office)
59 Garden Street
South Yarra, Victoria 3141
AUSTRALIA
☎ (03)241 - 1254

UNITED KINGDOM

Roland(U.K.) Ltd.
Rye Close
Ancells Business Park
Fleet, Hampshire GU13
8UY, UNITED KINGDOM
☎ 0252 - 816181

Roland(U.K.) Ltd.,
Swansea Office
Atlantic Close, Swansea
Enterprise Park, Swansea,
West Glamorgan SA79FJ,
UNITED KINGDOM
☎ (0792)700 - 139

ITALY

Roland Italy S. p. A.
Viale delle Industrie 8
20020 ARESE MILANO
ITALY
☎ 02 - 93581311

SPAIN

Roland Electronics
de España, S. A.
Calle Bolivia 239
08020 Barcelona, SPAIN
☎ 93 - 308 - 1000

GERMANY

Roland Elektronische
Musikinstrumente
Handelsgesellschaft mbH.
Oststrasse 96, 2000
Norderstedt, GERMANY
☎ 040/52 60 090

FRANCE

Musikengro
102 Avenue Jean-Jaures
69007 Lyon Cedex 07
FRANCE
☎ (7)858 - 54 60

Musikengro (Paris Office)
Centre Region Parisienne
41 rue Charles-Fourier,
94400 Vitry s/Seine
FRANCE
☎ (1)4680 86 62

BELGIUM/ HOLLAND/ LUXEMBOURG

Roland Benelux N. V.
Houtstraat 1
B-2260 Oevel-Westerlo
BELGIUM
☎ (0032)14 - 575811

DENMARK

Roland Scandinavia A/S
Langebrogade 6
Box 1937
DK-1023 Copenhagen K,
DENMARK
☎ 31 - 95 31 11

SWEDEN

Roland Scandinavia A/S
DanvikCenter 28 A, 2 tr.
S-131 30 Nacka
SWEDEN
☎ 08 - 702 00 20

NORWAY

Roland Scandinavia
A/S
Lilleakerveien 2
Postboks 95 Lilleaker
N-0216 Oslo 2
NORWAY
☎ 02 - 73 00 74

FINLAND

Fazer Musik Inc.
Länsituulentie
POB 169
SF-02101 Espoo
FINLAND
☎ 0 - 43 50 11

NEW ZEALAND

Roland Corporation
(NZ) Ltd.
97 Mt. Eden Road, Mt.
Eden, Auckland 3,
NEW ZEALAND
☎ (09)3098 - 715

SWITZERLAND

Musitronic AG
Gerberstrasse 5, CH-4410
Liestal, SWITZERLAND
☎ 061/921 16 15

Roland CK (Switzerland)
AG
Postfach/Hauptstrasse 21
CH-4456 Tenniken
SWITZERLAND
☎ 061/98 60 55
Repair Service by
Musitronic AG

AUSTRIA

E. Dematte & Co.
Neu-Rum Siemens-
Strasse 4
A-6021 Innsbruck Box 591
AUSTRIA
☎ (0512)63 451

GREECE

V. Dimitriadis & Co. Ltd.
2 Phidiou Str., GR 106 78
Athens, GREECE
☎ 1 - 3620130

PORTUGAL

Casa Caius Instrumentos
Musicais Lda.
Rua de Santa Catarina 131
Porto, PORTUGAL
☎ 02 - 38 44 56

HUNGARY

Intermusica Ltd.
Warehouse Area 'DEPO'
Torokbalint, Budapest
HUNGARY
☎ (1)1868905

ISRAEL

D.J.A. International Ltd.
25 Pinsker St., Tel Aviv
ISRAEL
☎ 972 - 3 - 5283015

CYPRUS

Radex Sound Equipment
Ltd.
17 Panteli Katelari Str.
P.O.Box 2046, Nicosia
CYPRUS
☎ 453426, 466423

TURKEY

Barkat Sanayi ve Ticaret
Siraselviler Cad. 86/6
Taksim Istanbul, TURKEY
☎ 149 93 24

EGYPT

Al Fanny Trading Office
9, Ebn Hagar Askalany
Street, Ard El Golf,
Heliopolis, Cairo, EGYPT
☎ 2917803 - 665918

BRAZIL

Roland Brasil Ltda.
R. Alvarenga 591
CEP-05509 Sao Paulo
BRAZIL
☎ (011)813 - 7967
Repair Service for Roland
and Rhodes products

Oliver do Brasil S.A.
Instrumentos Musicais
Av. Ceci, No.578 Centro
Empresarial Tambore
Barueri SP CEP 06400
BRAZIL
☎ (011)709 - 1267
Repair Service for BOSS
products

MEXICO

Case Veerkamp, s.a. de c.v.
Mesones No. 21
Col. Centro
C.P. 06080 Mexico, D.F.
MEXICO
☎ (5)709 - 3716

La Casa Wagner de
Guadalajara s.a. de c.v.
Av. Corona No. 202 S.J.
C.P.44100
Guadalajara, Jalisco
MEXICO
☎ (36)13 - 1414

ARGENTINA

Netto S.A.
Venezuela 1433
1095 Buenos Aires
ARGENTINA
☎ 37 - 1632

HONG KONG

Tom Lee Music Co., Ltd.
Service Division
22-32 Pun Shan Street,
Tsuen Wan, New
Territories, HONG KONG
☎ 415 - 0911

KOREA

Cosmos Corporation
Service Station
261 2nd Floor Nak-Won
arcade
Jong-Ro ku, Seoul, KOREA
☎ (02) 742 8844

SINGAPORE

Swee Lee Company
Bras Basah Complex
#03-23 Singapore 0178
SINGAPORE
☎ 3367886

THAILAND

Theera Music Co., Ltd.
330 Verng Nakorn Kasem,
Soi 2, Bangkok 10100,
THAILAND
☎ 2248821

MALAYSIA

Syarikat Bentley
No.142, Jalan Bukit
Bintang 55100 Kuala
Lumpur, MALAYSIA
☎ 2421288

INDONESIA

PT Galestra Inti
Kompleks Perkantoran
Duta Merlin Blok C/59
Jl. Gajah mada No.3-5
Jakarta 10130
INDONESIA
☎ (021) 354604, 354606

TAIWAN

Siruba Enterprise(Taiwan)
Co., LTD.
Room. 5, 9fl. No. 112
Chung Shan N.Road Sec.2
Taipei, TAIWAN, R.O.C.
☎ (02)5364546

SOUTH AFRICA

That Other Music
Shop(PTY) LTD.
256 Bree Street,
Johannesburg 2001
Republic of South Africa
☎ 337 - 6573

Paul Bothner(PTY) LTD.
17 Werdmuller Centre
Claremont 7700
Republic of South Africa
☎ 021 - 64 - 4030

AR-1000 QUICK REFERENCE GUIDE

RECORDING


Prepare for Recording

- AR-1000
KEY PROTECT switch → OFF
- Memory Card
Protect switch → OFF

Different Types Offered (Sampling Rates)

1. 8.5 k : To get the longest recording time.
2. 17 k : For ordinary recording.
3. 22 k : To enjoy the highest quality recordings.


1 RECORDING MODE



1. Press [REC MODE].
2. Select the Phrase using [△]/[▽].

REC MODE 0120
A001| | | | | | | |


2 SET THE TYPE



1. Use [▶] to move the blinking cursor to Type.
2. Select the type using [△]/[▽].

REC MODE 0120
A001|1|100|00|000


3 RECORDINGSTANDBY



Hold down [STOP] while you press [START].

===== PAUSE
A001|1|100|00|000


4 RECORDING LEVEL



Use the INPUT LEVEL knob to adjust the recording level. At the ideal level, the "■" should not light at all.

===== PAUSE
A001|1|100|00|010


5 BEGIN RECORDING



1. Press [START] to start recording.
2. Press [STOP] to stop recording.

===== REC
A001|1|100|00|010

6 FINISH



Press [EXIT] to leave the recording mode.

MONITOR 0110
A001|1|100|00|010

MONITORING

- Do the following to listen to recordings on the memory card.

1 MONITOR MODE

KEY PROTECT

OFF ON (PLAY MODE)

Slide the KEY PROTECT switch to OFF.

```

MONITOR
A001|1|90|00|010
    
```

2 SELECT THE PHRASE

START STOP REC MODE EDIT

ENTER EXIT

- Using [**◀**], select card A or B.
- Select the Phrase using [**▲**]/[**▼**].

```

MONITOR
A001|1|90|00|010
    
```

3 START/STOP PLAYBACK

START STOP REC MODE EDIT

ENTER EXIT

- Press [**START**] to start playback.
- Press [**STOP**] to stop playback.

```

MONITOR      PLAY
A001|1|90|00|010
    
```

FORMATTING

- Memory cards need to be formatted before the AR-1000 is able to use them.

IMPORTANT!

Never remove the memory card from the slot while it is being formatted.
Slide the write protect switch on the memory card to the "OFF" position.

1 INSERT MEMORY CARD

Brand new, or otherwise not formatted memory card.

* Slide the KEY PROTECT switch to OFF.

```

CARD Format
CARD A|512KBytes
    
```

2 FORMAT IT

START STOP REC MODE EDIT

ENTER EXIT

Press [**ENTER**] to begin formatting the card.

```

Formatting
CARD A|512KBytes
    
```

3 COMPLETION

Once formatting has completed, the display will show the message below.

```

NO PHRASE
    
```


Actual time remaining when playing back/recording Phrases versus what is shown in the display

Although the AR-1000 internally carries out all its processing of Phrases in milliseconds, the display can only express time in whole seconds. the display will round off the time value to the nearest second in one of two ways, depending on whether it is in playback or recording, as follows:

● When indicating the remaining recording time, the fractional part is ignored:

Ex.) Remaining Recording Time → 2.5 (sec)
Display shows → 2 (sec)

● When indicating the remaining playback time, the value is rounded to the next highest whole number:

Ex.) Remaining Playback Time → 2.5 (sec)
Display shows → 3 (sec)

CORRECTIONS

Please note that some corrections need to be made to the "AR-1000 Owner's Manual." Please accept our sincerest apologies for any inconveniences this may cause. The manual should read as follows:

■ Page 3 "Concerning Memory Cards"

● Correction for the Recording Time (in chart)

(Erroneous) 3M bytes (8.5kHz) → 735sec

(Correct) 3M bytes (8.5kHz) → 734sec

■ Page 25 "COPYING PHRASES"

(Erroneous) 1) Select the Phrase which is to become the source for the copy.

4) Specify the destination of the copy.

(Correct) 1) Select the Phrase which is to become destination for the copy.

4) Specify the source of the copy.

■ Page 30 "Displaying the Play Time for a Pattern Phrase"

(Erroneous) 2) Press the [EDIT] button, and you are returned to the page you were in before.

(Correct) 2) Press the [REC MODE] button, and you are returned to the page you were in before.

■ Page 67—68 "SPECIFICATIONS"

● Page 67 "Outputs"

(Erroneous) Load Impedance : 600 Ω or less

(Correct) Load Impedance : 600 Ω or more

● Page 68 "Display"

(Erroneous) 1 Line 20 character (Backlit LCD)

(Correct) 2 Line 16 character (Backlit LCD)

For Germany

Bescheinigung des Herstellers/Importeurs

Hiermit wird bescheinigt, daß der die das
ROLAND ANNOUNCEMENT RECORDER AR-1000
.....
(Gerät Typ Bezeichnung)

in Übereinstimmung mit den Bestimmungen der
Amtsbl. Vfg 1046/1984
.....
(Amtsblattverfügung)

funk-entstört ist.

Der Deutschen Bundespost wurde das Inverkehrbringen dieses Gerätes angezeigt und die Berechtigung zur Überprüfung der Serie auf Einhaltung der Bestimmungen eingeräumt.

Roland Corporation Osaka/Japan
.....

Name des Herstellers/Importeurs

For the USA

FEDERAL COMMUNICATIONS COMMISSION RADIO FREQUENCY INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Unauthorized changes or modification to this system can void the users authority to operate this equipment.

The I/O cable between this equipment and the computing device must be shielded.

For Canada

CLASS A

NOTICE

This digital apparatus does not exceed the Class A limits for radio noise emissions set out in the Radio Interference Regulations of the Canadian Department of Communications.

CLASSE A

AVIS

Cet appareil numérique ne dépasse pas les limites de la classe A au niveau des émissions de bruits radioélectriques fixés dans le Règlement des signaux parasites par le ministère canadien des Communications.

 Roland®

26055499

UPC

26055499



10981

AR-1000 ANNOUNCEMENT
RECORDER