

Additions to the RC-50 Owner's Manual

At the time of publication, the information below was not included in the "RC-50 Owner's Manual." Please add the following additional information to the Owner's Manual.

Switching Playback-start Operation

You can switch the manner for starting playback immediately when the REC/PLAY/OVERDUB pedal is operated while recording is in progress.

Priority Given to Rhythm (Factory Default)

This preserves the performance rhythm from the time that recording started.

When you operate the pedal, the performance-start location is adjusted and playback is started accordingly.

Although it may sometimes sound as if playback has started from the middle of a phrase, from the following loop, playback takes place as recorded.

Priority Given to Sound

This starts playback from the beginning of the recorded data.

Note, however, that for the rhythm guide, recorded phrases, or recordings synchronized with MIDI, playback starts with "Rhythm Priority."

How to Change the Operational Mode

1. To choose the mode you want to use, hold down the corresponding buttons described below as you switch on the power.

Check what's displayed on the title screen, then release the buttons.

Rhythm Priority: [LOOP SYNC] + [PHRASE 1]

Sound Priority: [LOOP SYNC] + [PHRASE 2]

- * The setting is saved in memory, so you don't need to carry out this procedure the next time you start up. You should carry out this procedure only when you want to change to a different mode.

RC-50 取扱説明書の追加事項

「RC-50 取扱説明書」には記載されていない補足事項があります。取扱説明書の内容を以下のように追加させていただきます。

再生開始動作の切替

録音中に REC/PLAY/OVERDUB ペダルを操作して、すぐに再生を開始する場合の動作を切り替えることができます。

リズム優先（工場出荷設定）

録音を始めた時からの演奏リズムをキープします。

ペダル操作時に、演奏開始位置を調節して再生を開始します。

フレーズの途中から始まったように聞こえる場合がありますが、次のループからは録音したとおりの再生が行われます。

サウンド優先

録音データの先頭から再生を開始します。

ただし、リズム・ガイドや録音済みのフレーズ、または MIDI に同期した録音が行われている場合は、「リズム優先」で再生開始されます。

動作モードの切り替えかた

1. 使いたいモードにあわせて以下のボタンを押しながら電源をオンにします。

タイトル画面表示されたのを確認してから、ボタンを離してください。

リズム優先: [LOOP SYNC] + [PHRASE 1]

サウンド優先: [LOOP SYNC] + [PHRASE 2]

- ※ 設定はメモリに保存されますので、次回起動時からはこの操作をする必要はありません。異なるモードに切り替えたい場合のみ、操作してください。